


5.8L with Coolant-Cooled Oil Cooler

NOTE: At 38°C (100°F) ambient temperature, green arrows indicate coolant temperature below 90°C (194°F), amber arrows indicate coolant temperature approximately 90°C (194°F), red arrows indicate coolant temperature above 90°C (194°F),



N0147498

Item	Part Number	Description
1	8A080	Engine cooling system degas bottle
2	8A586	Thermostat housing and hose assembly
3	8276	Upper intake manifold-to-engine system degas bottle hose
4	9424	Upper intake manifold
5	8D030	Supercharger cooling radiator-to-supercharger cooler hose
6	8D028	Supercharger cooling degas bottle
7	8501	Engine cooling system coolant pump
8	8D029	Supercharger cooling degas bottle-to-supercharger coolant pump hose
9	6049	RH cylinder head
10	9N491	Supercharger tube assembly
11	6K775	Supercharger cooler
12	18K580	Heater core outlet hose
13	18K579	Heater core inlet hose
14	18C553	Heater core hose and tube assembly
15	19B555	Heater core and evaporator housing
16	8050	LH cylinder head

17	6083	LH cylinder head gasket
18	18663	Heater outlet tube
19	6010	Engine block
20	6L635	Oil temperature control thermostat
21	6881	Oil filter adapter
22	6A642	Oil Cooler
23	8K232	Supercharger cooling system coolant pump
24	8B273	Lower radiator hose assembly
25	8K236	Supercharger cooling system coolant pump-to-radiator hose
26	8005	Engine cooling system radiator
27	8009	Supercharging cooling system radiator